

Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed, our products are designed for durability and for ease of erection.

Spare poles can be purchased to replace broken poles
\*\* awnings will not be swapped because of broken poles\*\*

## Please read the following instructions <u>carefully</u>

TIP: Refer to the photograph to help when pitching your Momentum Cayman

- Please do not leave for your vacation without fully erecting and checking the contents of your porch.
- Ideally erect your porch for some period allowing it to weather.
- Please make sure that before erecting, that you site the porch <u>on clear Level ground</u> with no sharp objects underneath, and that all the zips are fully closed. (We recommend laying a groundsheet down to keep the awning Dry and clean)
- If you have any issues relating to pitching your awning please contact your dealer for instructions before going on holiday.

## IMPORTANT PLEASE CHECK YOUR EQUIPMENT

(Make yourself familiar with the awning and its parts before attempting to erect)

Contents

Flysheet (or outer)

2 x Fibreglass poles
Pegs (in a separate bag)

Outer carrying bag (with dimension details)

A selection of spare parts

## **ERECTION INSTRUCTIONS.**

Outdoor revolution tents are all erected outer first

- 1. Lay the outer/flysheet spread out on the ground. Slacken adjusters off on the black tapes (near the ring and pin assemblies) around the foot of the awning.
- Open the pole bag and lay the poles out on the ground. Take one of the shaped fibreglass poles and open
  it out, then slide it diagonally through one of the seams on the roof and down to the bottom corner at the
  other side. Repeat the process with the other fibre pole, complete this by placing the steel pin on the 'ring
  and pin' assembly into the foot of the fibre pole. SPARE POLES CAN BE PURCHASED FROM
  WWW.OUTDOOR-REVOLUTION.COM, spares section.

- 3. You will find by now the awning has formed a dome shape and should now be standing.
  4. You are now ready to peg the awning out, (unless attaching to a motorhome- see notes below\*\*\*) Firstly, make sure all zips are closed. Starting at one corner; peg all the pegging points around the tent. (Take care not to over tighten the tent, if a door zip is tight it is probably stretched two tight)
- 5. Guy lines can now be tensioned and pegged on the awning and canopy, please ensure in heavy weather that ALL guy lines and stability straps are used. (Please note that failure to use all the lines may result in your tent being damaged)
- 6. You are now ready to back your vehicle up to the Awning. Offer up the 'tunnel' at the back of your awning to the desired position and secure the tunnel in place up to the roof of your vehicle. Then adjust the buckles and straps on either side of the tunnel to get a better fit and then finally tension the elastic toggles to create a better weather seal.

\*\*\*Note, to attach the awning to a Motorhome Fiamma/Omnistor you will need to purchase a driveaway kit consisting of double edged awning piping an figure 8 joining strips. Simply slide into the awning rail, then the tent is lined up and the figure 8 is positioned to join the two.

## Please note these few points for trouble free camping.

- a. After use please you always dry and air the tent before packing away.
- b. Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents as this will destroy the waterproofing on the fabrics.
- c. We advise that you DO NOT cook or smoke in this tent; although the outer fabric is fire retardant treated it will still melt.
- Please make sure that you have a good time.

\*\*We highly recommend that you insure your awning against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the caravan or vehicle because of misuse, incorrect pitching or extreme weather\*\*

> Outdoor Revolution Tents are distributed by: Blue Diamond Products Ltd